

CONFIDENTIAL FINAL REPORT

SPONSOR:

Chiaphua Industries Limited

SPONSOR'S REPRESENTATIVE:

Ian Van Trump

STUDY TITLE:

VIRUCIDAL HARD-SURFACE EFFICACY

TEST – Severe Acute Respiratory Syndromerelated Coronavirus 2 (SARS-CoV-2) (COVID-

19 Virus)

STUDY IDENTIFICATION:

Microbac Project No. 1025-101 (refer to signed

Protocol No. CHIA.1.05.29.20)

TEST AGENT NAME	LOT NO.	ACTIVE INGREDIENTS	DATE RECEIVED	DS NO.
Germagic Thyme	GMTP-HKUST2020060201	Thyme Essential Oil, Polyethylenimine,	06/18/20	K858
Oeimagic myme	GMTP-HKUST2020060901	Polyhexanide	06/18/20	K859

CHALLENGE ORGANISM:

SARS-CoV-2 (COVID-19 Virus), Strain: USA-WA1/2020, Source: BEI Resources, NR-52281

HOST CELL LINE:

Vero E6 cells, ATCC CRL-1586

DILUTION MEDIUM:

Minimum Essential Medium (MEM) + 2%

Newborn Calf Serum (NCS)

NEUTRALIZER:

MEM + 10% NCS + 0.5% Lecithin + 1 mM EDTA

CONTACT TIME:

9 minutes 55 seconds

CONTACT TEMPERATURE:

Room Temperature (20±1°C, Actual: 21°C)

RELATIVE HUMIDITY:

48-49% RH

NUMBER OF REPLICATES:

1 replicate (four wells per dilution)

Page 1 of 6

INCUBATION TEMPERATURE: 36±2°C with 5±3% CO₂

INCUBATION TIME: 4 - 9 days (Actual: 7 days)

DILUTION OF TEST AGENT: Ready to use

ORGANIC LOAD: 5.0% serum

CARRIER INOCULATION AND DRY TIME: Glass Petri dishes with marked areas of 4-square inches were inoculated with 0.4 mL of the challenge organism and dried for 46 minutes at 21°C and 49-52% RH.

TEST APPLICATION: Carriers were sprayed with three pumps until thoroughly wet from a distance of 6 – 8 inches.

CALCULATION OF TITER: The 50% tissue culture infectious dose per mL (TCID₅₀/mL) was determined using the Spearman-Karber method using the following formula:

$$m = x_k + \left(\frac{d}{2}\right) - d\sum p_i$$

where:

m = the logarithm of the dilution at which half the wells are infected relative to the test volume

 x_k = the logarithm of the smallest dosage which induces infection in all cultures

d = the logarithm of the dilution factor

p_i = the proportion of positive results at dilution i

 $\sum p_i$ = sum of p_i (starting with the highest dilution producing 100% infection)

The values were converted to TCID₅₀/mL using a sample inoculum of 1.0 mL.

RESULTS:

Results are presented in Tables 1–6.

The Log₁₀ Reduction Factor was calculated in the following manner:

Log₁₀ Reduction Factor = Initial viral load (Log₁₀ TCID₅₀, per assayed volume and per carrier) – Output viral load (Log₁₀ TCID₅₀, per assayed volume and per carrier)

The Load (Log₁₀ TCID₅₀) per carrier was calculated in the following manner:

Virus Load ($Log_{10} TCID_{50}$) = Virus Titer ($Log_{10} TCID_{50}/mL$) + Log_{10} [Volume per sample (mL)]

Key (for all tables):

- T/y = Cytotoxicity observed in y wells inoculated; viral cytopathic effects (CPE) could not be determined
- X/y = X wells out of y wells inoculated exhibited positive viral CPE
- 0/y = 0 out of y wells inoculated exhibited positive viral CPE; no cytotoxicity or bacterial contamination was observed in any of the wells inoculated

RESULTS (Continued):

Table 1
Plate Recovery Control (PRC)

Dilution*	PRC	
Dilation	Replicate 1	
10 ⁻³	4/4	
10 ⁻⁴	4/4	
10 ⁻⁵	4/4	
10 ⁻⁶	3/4	
10 ⁻⁷	1/4	
10 ⁻⁸	0/4	
Titer (Log ₁₀ TCID ₅₀ /mL)	6.50	
Load (Log ₁₀ TCID ₅₀)**	6.10	

^{*}Dilution refers to the fold of dilution from the virus inoculum.

Table 2
Test Agent

Dilution*	Germagic Thyme		
Dildton	Lot No. GMTP-HKUST2020060201	Lot No. GMTP-HKUST2020060901	
10-2	T/4	T/4	
10-3	T/4	T/4	
10-4	0/4	0/4	
10 ⁻⁵	0/4	0/4	
10-6	0/4	0/4	
10 ⁻⁷	0/4	0/4	
Titer (Log ₁₀ TCID ₅₀ /mL)	≤ 3.50	≤ 3.50	
Load (Log ₁₀ TCID ₅₀)**	≤ 3.10	≤ 3.10	
Log ₁₀ Reduction***	≥ 3.00	≥ 3.00	

^{*}Dilution refers to the fold of dilution from the virus inoculum.

Microbac

^{**}Per carrier (0.4 mL of Undilute [100])

^{**}Per carrier (0.40 mL of Undilute [100])

^{***}Per assayed volume and per carrier

RESULTS (continued):

Table 3
Neutralizer Effectiveness/Viral Interference (NE/VI) and Cytotoxicity (CT) Controls

	Germagic Thyme		
Dilution*	Lot No. GMTP-HKUST2020060201		
	NE/VI	СТ	
10 ⁻²	T/4	T/4	
10-3	T/4	T/4	
10-4	4/4	0/4	

^{*}Dilution refers to the fold of dilution from the mock inoculum.

Table 4
Neutralizer Effectiveness/Viral Interference (NE/VI) and Cytotoxicity (CT) Controls

	Germagic Thyme Dilution* Lot No. GMTP-HKUST2020060901	
Dilution*		
	NE/VI	СТ
10-2	T/4	T/4
10-3	T/4	T/4
10-4	4/4	0/4

^{*}Dilution refers to the fold of dilution from the mock inoculum.

Table 5
Cell Viability Control (CVC)

	CVC
	0/4
Cells were viable; media was sterile	

RESULTS (continued):

Table 6
Virus Stock Titer Control (VST)

Dilution*	VST	
10-4	4/4	
10 ⁻⁵	4/4	
10-6	4/4	
10 ⁻⁷	3/4	
10-8	0/4	
10 ⁻⁹	0/4	
Titer (Log ₁₀ TCID ₅₀ /mL)	7.25	

^{*}Dilution refers to the fold of dilution from the virus inoculum.

CONCLUSION:

According to the US Environmental Protection Agency, the test agent passes the Virucidal Hard-Surface Efficacy Test if the product demonstrates $a \ge 3 \log_{10}$ reduction on each surface in the presence or absence of cytotoxicity. When cytotoxicity is present, the virus control titer should be increased, if necessary, to demonstrate $a \ge 3 \log_{10}$ reduction in viral titer on each surface beyond the cytotoxic level.

Germagic Thyme, Lot No. GMTP-HKUST2020060201: passed
 Germagic Thyme, Lot No. GMTP-HKUST2020060901: passed

The viral reductions for the test agent are presented in Table 2. All controls met the criteria for a valid test. These conclusions are based on observed data.

Study Director:

Cameron Wilde

Date